

# IRISPhoto™ 4



## Scan all your photos! No computer needed!

- Scan up to 2,000 photos to the built-in memory!
- Runs on internal rechargeable battery.
- So easy-to-use, anyone can do it.



### Quick reference guide

Product name	IRISPhoto™ 4
MSRP	99 USD
UPC code	765010721153
SKU	457085
Box size	9.74 (W) x 3.24 (H) x 7.71 (D) inches
Scanner size	6.2 (W) x 1.7 (H) x 2.1 (D) inches
Scanner weight	+/- 0.5lbs
Box language	English
Box content	<ul style="list-style-type: none"> <li>• IRISPhoto™ 4 scanner</li> <li>• USB cable</li> <li>• Calibration sheet</li> <li>• 2 plastic photo holders</li> <li>• Cleaning swab</li> <li>• Software suite for Mac® and PC on CD ROM</li> </ul>

### INCLUDED



Lightning-fast and easy to use, ACDSee™ will help you organize and share your photos with friends and family.

ACDSee™ Photo Manager 12 for Windows®  
ACDSee™ Express 2 for Mac®.

### Computer minimum requirements

- A CD Rom drive and a free USB port.
- Can be used on any operating system supporting mass storage protocol (Windows®, Mac OS®, Linux®, Unix®, etc.).
- Works without installing any driver.

### ACDSee™ system requirements for Windows®

- An Intel® Pentium® III / AMD Athlon™ processor or equivalent. (Intel® Pentium® 4 / AMD Athlon™ XP or equivalent recommended).
- 512 MB RAM (1 GB RAM recommended).
- 250 MB of free disk space (1 GB recommended).
- Internet Explorer® 6.0 (7.0 or higher recommended).
- The Windows® 7, Vista® or XP with Service Pack 2 operating system.

### ACDSee™ system requirements for Mac OS®

- A Mac® computer with an Intel® processor.
- 512 MB RAM, 1 GB recommended.
- 100 MB of free disk space.
- Mac OS® X version 10.5.8 or above.



## Scan all your photos! No computer needed!





Photo Management Software

acdsee

**1** Quickly scan your photos. No computer needed!

**2** Transfer your photos to your computer (USB cable provided).

**3** Organize your photos!

Lightning-fast and easy to use, the IRISPhoto™ 4 will help you scan, organize and share your photos with friends and family.



### Super compact, super portable

Weighing less than 6 oz., the IRISPhoto™ 4 easily fits in your briefcase, purse, etc. and even your pocket!



### For photos of any size

Scan up to 4 x 6" photos in seconds. Supports portrait or landscape scanning.



### Internal memory of 512 MB

No SD card? No problem. Just scan to the internal memory!



### SD card

Use a SD, xD, MS, MS Pro, MMC card to expand your storage capacity.



### Battery powered

Charge the scanner. Unplug it. Take it everywhere you need it.



The easy way to organize and share your photos. Who does not have boxes of photos you'd love to scan, organize and share with friends and family?

ACDSee™ Photo Manager 12 for Windows® - ACDSee™ Express 2 for Mac®.

### PHOTO SCANNER SPECIFICATIONS

Document feeding	Sheet feed type
Resolution	300 dpi (600 dpi if the photo is scanned with the plastic photo holder)
Document size (max)	Up to A6/4 x 6"
Interfaces	<ul style="list-style-type: none"> <li>• SD, xD, MS, MS Pro, MMC (for optional memory)</li> <li>• USB Slave (type-B Mini) (for computer connection)</li> </ul>
Output file format	JPEG
Flash memory	512 MB (expandable with SD card)
Battery	<ul style="list-style-type: none"> <li>• Lithium-ion polymer rechargeable battery through USB cable</li> <li>• Scanning capacity when fully charged : up to 150 pages @ 4 x 6" based on test conditions in 300 dpi mode</li> </ul>
Charging method	USB cable



© Copyright 2010 I.R.I.S. s.a./n.v. - All rights reserved for all countries. I.R.I.S., I.R.I.S.' product names, I.R.I.S.' logos and I.R.I.S.' product logos are I.R.I.S. trademarks. All other products and names mentioned are trademarks or registered trademarks from their respective owners.

[www.irislink.com](http://www.irislink.com)