

## Safety Instructions

Follow these safety instructions when setting up and using the scanner:

- Read all these instructions, and follow all warnings and instructions given in this document.
- Place the scanner close enough to the computer for the interface cable to reach it easily.
- Never handle the scanner with damp or wet hands, in nomadic mode, or when used as a fixed unit.
- When connecting this product to a computer or other device with a cable, ensure the correct orientation of the connectors. Each connector has only one correct orientation. Inserting a connector in the wrong orientation may damage both devices connected by the cable.
- Other than placing a mini SD card or new batteries in the openings provided for the purpose and indicated on the scanner, do not insert objects into any opening as they may touch dangerous voltage points or short out parts and lead to a risk of electrocution.
- Place the product on a flat, stable surface large enough to safely hold the product and the document to be scanned.
- Never disassemble the scanner.
- If the product overheats or produces smoke or an unusual odour, discolours or becomes deformed in an abnormal way, immediately turn off the scanner, remove the batteries where applicable, and disconnect the cables. Stop using the scanner and contact your dealer or I.R.I.S. customer support to receive instructions on the procedure to follow.
- Take care not to drop the scanner or expose it to physical impacts.
- Do not place or store the scanner outdoors, in a car, near heat sources, in locations that are dusty, damp or exposed to impact, vibration, condensation, high temperatures, sunlight, strong light, or rapid changes in temperature or humidity.
- Never attempt to disassemble, modify, or repair the scanner or any of its components yourself.
- Special precaution concerning the model equipped with Wifi transmission or Bluetooth (IRIScan Book Executive 3, IRIScan Anywhere 3 Wifi, IRIScan Pro 3 Wifi, IRIScan Book 5 Wifi, IRIScan Anywhere 5 Wifi, IRISNotes Air 3, IRISPen Air 7, IRIScan Anywhere 6 wifi):
  - Radio waves from this product may adversely affect the operation of other devices, such as medical equipment, measuring instruments in aeroplanes, or automatically controlled devices, such as pacemakers, automatic doors, or fire alarms, and any other device that is sensitive to radio waves.
  - When using this product near such devices or inside a medical facility, follow the directions marked on the devices concerned and the instructions for authorized staff members at the facility, and follow all posted warnings and directions on the device to avoid causing an accident.

IRIS sa  
Rue du Bosquet 10  
1348 Louvain-la-Neuve  
Belgium  
Phone: +32-(0)10-45 13 64  
Fax: +32-(0)10-45 34 43  
[marketing.distri@irisincorporate.com](mailto:marketing.distri@irisincorporate.com)  
[www.irislink.com](http://www.irislink.com)

IRIS inc.  
955 NW 17th Avenue, Unit D  
Delray Beach, Florida 33445  
United States  
Phone: +1 (561) 921 0847  
Fax: +1 (561) 921 0854  
[Marketing.distri@irisincorporate.com](mailto:Marketing.distri@irisincorporate.com)  
[www.irisusa.com](http://www.irisusa.com)